

How to Install the Wire Shelving



You need :

1. A pencil
2. A ruler and a tape measure
3. A battery powered drill
4. The saddles supplied with the product
5. The screws supplied with the product



Having removed the stock from the shelf you wish to place the new shelving on, with a ruler measure 90mm from the bottom of the shelf and make a mark with a pencil.

Do this at intervals of 500mm along the length of the shelf.

Draw a faint pencil line joining these marks. This gives you the line to ensure your wire shelf is installed in line with your existing shelf.



Apply the saddles to the shelf with two required per length of wire shelving.

Place the screw on the tip of the drill and screw through the saddle until the head of the screw is flush with the saddle.

This will secure the wire shelf above your timber shelf.

This type of fixing means that you can easily lift the wire shelf to clean the timber shelf.

The finished result - if you have any problems please call us for assistance



Easy to clean



Hold firm



Good copy depth