

How to Remove the Hublock (Case unlocked)

Step 1



Insert the side containing the DVD and hublock (that is to be removed) fully into the hublock release unit with the DVD and hublock facing you.



Case unlocked

Step 2



WARNING :

Do not squeeze the release unit handles together at this point.

Using your open hand gently push the handle forward toward the DVD as far as it will go.

Step 3



Now (with the handles still in the forward position) gently squeeze the handles together (no force is necessary).

Now, whilst keeping the handles (gently) squeezed together, slide the handles back to their original resting place.

Step 4



Now you can release the handles. The hublock will drop into the hublock catcher. Remove the Case and the disc is ready for hire.

The 3 steps together take just a second or two.