

## How to Install the Hublock Release Machine

**Please Note: Your Hublock Release Machine must be secured to a suitable fixed surface.**

### Equipment:

1. A Power Drill (preferably cordless)
2. A 2mm pilot drill bit
3. A Philips Head Screwdriver
4. 4 x 30mm x 10g self tapping screws or similar to suit your counter
5. A pencil to lightly mark the intended position on the counter
6. A ruler to measure and ensure proper positioning
7. Small punch or similar to mark exact drill hole locations

### Step One: Temporary Attachment - Using Double-Sided Adhesive Tape

1. Decide on the most convenient or practical location for your machine.
2. Place the machine on the counter as shown in the diagram, with the 'catcher' draw facing the front.
3. Slide the Hublock Catcher draw into place to check that it moves in and out easily.
4. Use a pencil to mark a line around the base of the machine.
5. Turn the machine over and remove the backing from the adhesive tape.
6. Carefully place the machine inside the pencil outline from Step 4. Press down to engage the tape.

### Step Two: Permanent Attachment - When Satisfied with the Location

1. Mark and punch the hole locations using the existing 4 slots as a guide.
2. Drill holes into your counter using the 2mm pilot drill bit.
3. Screw the machine to the counter.
4. Fit the Hublock Catcher draw.

The machine is now ready for use.

**Read User Guide - Sheet 4 - 'How to Remove the Hublock' carefully before first use.**



Machine position



Screw to counter here